

# DRAFT

## CSC ASM II Board

K. Vetter  
29-Nov-99

### INTRODUCTION

The purpose of this document is to describe the design goals and functionality of the prototype ASM (ASM II) board used on the CSC chamber.

The primary design objective is to develop an ASM board quickly that will serve as a test-bed for the CSC front end electronics and SCA controller development. This includes the characterization of the NEVIS SCA, AD9220 ADC and Pre-Amp. The second objective is to be able to use the ASM II board in the June-2000 CSC beam test at CERN.

### ASM II BOARD

The ASM II board will have one SCA producing twelve channels. Four selectable analog channels for real-time analysis are also provided. Configurable parameters include number of samples, number of samples prior to trigger and analog channel select. Parameters are selected by on-board switches or via remote control link.

Unlike the Liquid Argon configuration the SCA will be biased at +5v and GND. This biasing arrangement changes the logic levels to the SCA. We hope to be able to adjust the bias current to the logic inputs on the SCA such that a threshold voltage of +1.2v above ground is achieved. By doing this the digital control lines of the SCA will be LVDS compatible.

Included are four analog channels for real-time analysis. Data is multiplexed into four FIFO's during the SCA read sequence. The data is then re-timed by reading the FIFO's at the 5MHz SCA readout rate upon completion of the SCA read sequence.

Digital data from the ADC is made available for transmission to a data acquisition system. The signals will be transmitted using LVDS to maximize noise immunity over an approximate 100ft span during beam test. The ADC data is sent in parallel to an on-board HP G-Link fiber optic transceiver.

A functional block diagram for the CSC ASM II board is shown below. It should be noted that the pre-amp will not reside on the ASM II board. The pre-amp will be tested with the ASM II as two interconnected separate assemblies.



EPC2 EPROM. This makes it possible to reprogram the controller in-circuit via the JTAG (IEEE 1149.1) interface.

The first-order SCA controller will not incorporate the list processor scheme. The controller will be capable of reading out SCA data based on user selectable starting pre-trigger address, and selectable number of channel sample points.

Four [12x144] FIFO's are included that are capable of storing a complete SCA channel. The FIFO's are preceded by an ADC multiplexor that selects 4 of 12 channels to be stored in the FIFO's. The channel selection is programmable via on-board switches or remote control.

Upon reception of an external trigger the controller inhibits the SCA write clk (Wclk) and begins the SCA readout sequence. The SCA is readout at a rate of 5MHz. The FIFO's are filled at a rate depending of the number of samples per channel since the SCA is readout on a rotating sample per channel basis (i.e. c1s1,c4s1,c7s1,c10s1,c2s1,c5s1,c8s1,c11s1,c3s1,c6s1,c9s1,c12s1,c1s2). After the SCA readout process is complete a state machine is initialized to begin the FIFO readout process. The FIFO's are re-timed to the SCA readout clock of 5MHz. Each FIFO channel is 12 bits.




Figure 2.

## DATA AQUISITON AND TEST

Although four channels are provided on the ASM II for real-time analysis on an oscilloscope it would be desirable to capture the ADC digital data. This is not only desirable for development at BNL, but a requirement for beam test. A proposed Data Acquisition system for beam test is shown below in figure 3. Data from the ASM II would be captured by a high speed PCI based plug-in data acquisition card. One possible solution is the Gage Compuscope 3200 capable of capturing 32-bits of data at 100MHz. This would meet the 5MHz burst data rate from the ASM II.

The second requirement is to be able to remotely control parameters on the ASM II board. A possible solution would be to use the Gage 3250 plug-in card. This product is capable of sending 32-bit digital words at 50MHz. Control of the 3250 can be accomplished using either Gage software, or LabView drivers from Gage. Other solutions based on PC data acquisition from companies such as National Instruments are also being evaluated.

An advantage of this system is that all data would be available via network or internet. It would then be possible to copy files for analysis using Unix based programs such as PAW.




Figure 3.